


ELECTRICAL

The Speedheat heater is classified as an electrical appliance. All electrical connections, including the connection of the thermostat must be undertaken by a licensed electrician, in accordance with current electrical codes of practice, AS/NZS3000:2007 and state codes.


The heater element must be connected to a circuit with RCD protection. Please ensure any existing cabling and RCD's already installed are working correctly and capable of handling the additional load for the floor heating as specified.



CONNECTION DETAIL - FIXED WIRING



CONNECTION DETAIL - PLUG POINT



Electrical